SIEMENS

Important Note

Special terms and conditions

Please read carefully the following terms and conditions before opening this diskette(s) package.

You are responsible for the enclosed software products and documentation.

If you do not agree with them, you should return the package, unopened, as soon as possible.

Your money will then be refunded.

Siemens Aktiengesellschaft

SIEMENS

Agreement concerning the use of software products acquired against one payment

(Automation sectors)

Please, carefully read all the following terms and conditions which shall govern your use of the enclosed software product(s) and attached documentation. Opening the diskette cover indicates your full acceptance of these terms and conditions. If you do not accept them in full, please return the unopened diskette together with the complete documentation immediately. In this case, your money, if paid, will be refunded.

Your rights relating to the software product(s) contained in the attached diskette and written material are exclusively governed by the following provisions and you acknowledge to have read and understood them in full and to agree to be bound and strictly adhere by them.

Software Licensee Agreement

1 Definitions

1.1 "SIEMENS": Siemens Aktiengesellschaft, Berlin and Munich, Federal Republic of Germany and/or its affiliated companies and/or its authorized distributors;

1.2 "LICENSEE": the lawful recipient of the attached SOFTWARE and the attached SOFTWARE–DOCUMENTATION;

1.3 "SOFTWARE": the software product(s) on the attached medium;

1.4 "SOFTWARE–DOCUMENTATION": the attached set of written software documentation and parts thereof;

1.5 "SPS": the software product sheet attached hereto which is part of this agreement;

2 Rights

Upon receipt of the payment for use and subject to Section 8 Siemens grants to LICENSEE for an unlimited period of time the non–exclusive and non–transferable right to use the SOFTWARE and the SOFTWARE–DOCUMENTATION in accordance with the provisions below on the Siemens' hardware identified in the SPS and within the scope of the SOFTWARE/DOCUMENTATION.

3 Copying

3.1 LICENSEE has no right to copy the SOFTWARE, in whole or in part. However, LICENSEE may make three (3) copies of the SOFTWARE for archive purposes only.

3.2 LICENSEE has to right to copy the SOFTWARE–DOCUMENTATION, in whole or in part. Copies of the SOFTWARE–DOCUMENTATION are available against payment.

4 Proprietary Rights; Non–Disclosure

4.1 The SOFTWARE and SOFTWARE–DOCUMENTATION are trade secrets of the Siemens AG and/or its licensors and/or subject of other rights; such rights shall not be affected by these provisions; the names of the SOFTWARE are also protected. LICENSEE shall observe such rights and shall, in particular, not delete any copyright notices.

4.2 Neither the SOFTWARE including the archival copies thereof nor the SOFTWARE–DOCUMENTATION shall at any time be transferred, lent, leased of otherwise made available to any third party by LICENSEE.

5 Revision, Up–dates

The SOFTWARE and the SOFTWARE–DOCUMENTATION may, at Siemens' discretion, be revised and/or up–dated by Siemens. Revisions and/or up–dates will be furnished by siemens to LICENSEE, upon request of LICENSEE, against usual payments but only if Siemens has on its files a copy of the SPS filled out by LICENSEE.

6 Warranties

6.1 The SOFTWARE and the SOFTWARE–DOCUMENTATION are made available in the version identified in the SPS.

6.2 The period of warranty extends to six (6) months, beginning on the day the LICENSEE has provably received the SOFTWARE from Siemens. During such period Siemens assumes – on presentation of the original of the respective delivery note or the respective invoice – warranties as follows:

- the SOFTWARE was properly copied;
- the SOFTWARE runs on the hardware identified in the SPS
- the data media of the SOFTWARE is free from material and manufacturing faults.

The warranty obligations will be fulfilled by delivery of a substitute.

6.3 THE SOLE OBLIGATION OF Siemens UNDER WARRANTY SHALL BE THE FULFILLMENT OF THE OBLIGATIONS SET FORTH IN SECTION 6.2 Siemens EXPRESSLY DISCLAIMS ALL WARRANTIES EXPRESSED OR IMPLIED WITH RESPECT TO ANY CLAIM BY LICENSEE OF ANY THIRD PARTY ARISING FROM THE INCORRECTNESS OF THE SOFTWARE, ITS DATA STRUCTURES AND/OR THE SOFTWARE DOCUMENTATION AND/OR THE USE OF THE SOFTWARE AND/OR THE SOFTWARE DOCUMENTATION, INCLUDING BUT NOR LIMITED TO WARRANTIES OF MERCHANTABILITY AND FITNESS FOR LICENSEE'S PARTICULAR PURPOSE.

7 Liability

Siemens AG shall be liable for injury to persons for which Siemens AG may be held responsible and, in the event of damage to property for which Siemens AG may be held responsible, Siemens AG shall reimburse the cost of restoring such of restoring such property up to an amount of DM 1,000,000 (Deutsche Mark one million) for any one event. In the case of loss of damage to data carrying material the liability for damage does not include the cost of reconstructing lost data. Any further claims for damages other than the expressly specified compensation as in these provisions, in particular in respect to damage resulting from consultation, assistance in the installation of the SOFTWARE of errors in the SOFTWARE shall be excluded unless liability is mandatory in cases of intent, gross negligence or absence of assured characteristics.

8 Termination

This agreement and the rights granted herein shall terminate if LICENSEE fails to comply with any provision contained herein.

9 Amendments

Supplemental agreements and amendments to this agreement are not binding unless agreed upon writing.

Digitized by the Internet Archive
in 2025

https://archive.org/details/manualsplus_05276

SIEMENS

Software Product Sheet (SPS)

Type of use: single

Please retain this SPS certificate for your documents.
Please fill out and sign the **enclosed postcard** of this SPS and have it thereafter returned to the address of Siemens given below.

Licensee

Name _____

Department _____

Address _____

Postal Code City Street/square/no.

Siemens hardware product

CPU _____ Serial Number _____

Software Product

SIEMENS
K1197 DISK 1/4
For MF2.2
VN3 CONFORMANCE TESTS
TEST of TE / BRI V1.3
L2-SUB
7KK1197-8BL11
F-Nr:BF 9401-10 Pool: BF-94054151

Place, Dat _____ Signature of Licensee _____

Siemens AG
AUT3 MWB KQP
D–13623 Berlin

← Siemens address for returning enclosed postcard



SIEMENS

Protocol Tester K1197®

Conformance Tests with TTCN Test Manager for ISDN / NET – CTS

User Manual

Version September 1993

C73000–G6076–C509

© Siemens AG 1993

Dear Customer!

Please help us to improve our products. If you think, there's anything missing, or if you have any requests, please send the attached sheet to your local representative located nearest to your office and ask him to forward it to SIEMENS Karlsruhe, ANL A425–KRK, Germany as soon as possible.

For every error report we need the following information to find a solution as soon as possible:

- version number of the operating system and application software,
- detailed description of the error,
- list of commands typed in before the error occured,
- hardcopy of the screen when the error occured,
- hardcopy of the return stack backtrace, if it occured (press RETURN after command line window becomes red background),
- listing of the testscript, if the error was caused through in the testmanager,
- data recording file, if the error occured in the monitor.

To
Local Siemens Sales Office

Repeat order for device:

MLFB No. 7KK1197–1 _ _ _ _

(Machine–readable product designation No.)

Serial No. BF _ _ _ _ – _ _

(see rating plate on rear of device)

The following products are ordered:

Item
1
2
3
4

Customer Report — Protocol Tester K1197

To

Siemens AG

ANL A425–KRK

Siemensalle 84

D–76187 Karlsruhe

TEL +49 (0) 7 21–5 95 44 75
Fax +49 (0) 7 21–5 95 66 30

Tx
Ttx

From

_____

_____

_____

_____

_____

TEL
Fax

Tx
Ttx

Suggestions, Reports, Improvements:

Customer Report — Protocol Tester K1197

Soft– and Hardware used for test:

Application: _____ K1197 Type: _____

Version: _____ Serial–No.: _____

System+ Menu: _____

Options: ☐ Hard Disk ☐ RAM Extention ☐ other: _____

Tester Configuration:

☐ K1197 for monotoring

☐ K1197 for emulation/simulation as ☐ DCE / NT ☐ DTE / TE

Test environment: ☐ to another K1197

☐ other (Network, FAX Machine, etc.): _____

_____

_____

Error Description:

The error occurs: ☐ always ☐ sometimes

Encloses:

☐ Floppy Disk
☐ Testscript Listing
☐ Hardcopy/Printout
☐ other:

Date: **Signature:**

Dear Reader !

We provide you with technical documentation to support our products.

With your cooperation we can improve our product information if you answer the following questions:

Which definitions or descriptions do you not understand?	
What supplementary or additional information would you like to see included?	
Have you found any mistakes?	
Have you found any printing errors?	

Please send your answer and other suggestions to:

Siemens AG
AUT3 MWB KQP
D–13623 Berlin

Contents

Protocol Tester K1197®
Conformance Tests
with TTCN
Test Manager
for ISDN / NET – CTS

Copying of this document and giving it to others and the use or communication of the contents thereof,are forbidden without express authority. Offenders are liable to the payment of damages. All rights are reserved in the event of the grant of a patent or the registration of a utility model or design.

Subject to technical changes

Order No.: C73000–G6076–C509–3
Available from AUT3 K AZ Berlin
Printed in the Federal Republic of Germany
AG 0993 0.02 Repro En

1	SIETEM C73000–B6076–C511
2	NET1 C73000–M6076–C511
3	NET2 C73000–M6076–C512
4	NET3 C73000–M6076–C513
5	NET5 C73000–M6076–C546
6	CTS–2 Conformance Tests C73000–M6076–C548
7	CTS–WAN Conformance (X.25) C73000–M6076–C515
8	VN3 Conformance Tests C73000–M6076–C550
9	VN3 Interoperability Tests TE C73000–M6076–C551
10	

SIEMENS

Bestell-Nr. für Registersatz 6ZB5900-0AL00-8AA1
919112 06935.

SIETEM®
TTCN Test Manager

User Manual for Protocol Tester K1197

SIEMENS AG

System Version	:	MF 2.2.1
Software Version	:	V2.4
Revision Date	:	October, 1993
Engineering	:	AUT E33 D / SM
Quality Control	:	MWB KQP / 2.

RELEASE NOTES R–1

1 INTRODUCTION 1–1
1.1 SIETEM INTEGRATION IN K1197 1–2
1.2 ADVANTAGES OF THE 'SIETEM' IMPLEMENTATION 1–3
1.3 TEST SUITE STRUCTURE 1–4
1.4 SIETEM IN COMPARISON WITH STANDARD NOTATION 1–5
1.5 SIETEM USED WITH ISDN(ETSI) 1–6
1.5.1 GENERAL 1–6
1.5.2 TEST HANDLING 1–7

2 MENU SYSTEM 2–1
2.1 PARAMETER AND TEST SELECTION MENU 2–1
2.1.1 PARAMETER MENU 2–3
2.1.2 TEST CASE SELECTION MENU 2–4
2.2 SPECIAL FUNCTIONS 2–5
2.2.1 VERDICT LOG (VLOG) 2–5
2.2.2 STATISTICS 2–6

3 SIETEM PARAMETERS 3–1
3.1 LOG_SELECT 3–3
3.1.1 TEST ENVIROMENT 3–3
3.1.2 LOG REPORT PARAMETERS 3–3
3.1.3 DISK LOG PARAMETERS 3–4
3.1.4 PRINT LOG PARAMETERS 3–5
3.1.4.1 REPORT PARAMETER FOR X.25 3–5
3.1.4.2 REPORT PARAMETERS FOR ISDN 3–6
3.1.4.3 REPORT PARAMETERS FOR CCS#7 3–7
3.1.5 TEST SUITE EXECUTION CONTROL PARAMETERS 3–9
3.1.6 LOG OUTPUT PARAMETERS 3–10
3.1.7 VERDICT LOG PARAMETERS 3–11
3.1.8 PRELLIMINARY VERDICT PARAMETERS 3–12

4 SOFTWARE INTERFACES TO MENU SYSTEM 4–1
4.1 INTERFACE TO BASIC–SOFTWARE 4–1
4.2 INTERFACE TO TEST CASES. 4–2

5 INDENTATION COMPILER 5–1
5.1 FEATURES OF COMPILER 5–2
5.1.1 TEST STEP ATTACHMENT 5–2
5.1.2 DEFAULT BEHAVIOUR 5–3
5.1.3 EXIT TESTSTEP / CASE 5–5
5.1.4 RESCAN 5–5
5.1.5 REMAIN 5–6

6 TEST STEP, CASE, GROUP, SUITE 6–1
6.1 DEFINE TEST CASES / STEPS 6–2
6.2 CREATE SIETEM TREE STRUCTURE 6–3
6.3 ATTACH THE TEST SUITE TO THE MENU SYSTEM 6–4

7 CASE SELECTION TOOL 7–1

8	**VERDICTS**	**8–1**
8.1	VERDICT WORDS	8–1
8.2	TEST RUN	8–2
9	**TEST SUITE EXAMPLE**	**9–1**
10	**PICS/PIXIT PARAMETERS**	**10–1**
10.1	DEFINE PICS/PIXIT–OBJECTS	10–2
10.2	CREATE A NEW MENU SYSTEM ENTRY	10–4
10.3	EXAMPLE	10–5
10.4	WORDS USED BY FUNCTION: SAVEPARAM	10–5
10.5	' METHOD '	10–6
11	**OTHER WORDS**	**11–1**
11.1	DEBUGGING WORDS	11–1
11.1.1	' SPY '	11–2
11.2	VECTORED OUTPUT WORDS	11–3
11.2.1	SELECT THE OUTPUT CHANNEL	11–4
11.3	TREE	11–5
11.4	'DOER' WORDS	11–6
12	**SDL TESTMANAGER AND SIETEM**	**12–1**
12.1	OVERVIEW	12–2
12.2	ENHANCEMENTS FOR SIETEM	12–2
12.3	SOURCE FILES ON BINARY DISKETTE	12–3
12.4	EXAMPLE	12–6
INDEX		**I–1**

Program:	SIETEM
Software Version:	V2.4
Previous Version:	V2.3
System Version:	MF 2.2.1
Revision Date:	October, 1993

☞ *Please note that it is important to read this paper before reading the manual. Some functions may*
☞ *be used in another way as described in the manual since we have had some changes after*
☞ printing the manual.

Enhancements

- **In playback Date and Time will now be displayed in a new line.**
- **PARAMETER LIST –** *LOG_SELECT* **has changed.**
- **The word** *P* **is now "atcm"–dependent.**
- *TMTM.Bx* **(in ISDN) will now be loaded with the word** *EXECTS* **instead of** *EXECF*

1 INTRODUCTION

SIETEM® means SIEmens TTCN TEst Manager

Is is designed for Acceptance / Conformance Tests with special interactive features.

Test Configuration:



For further details see special manuals

SIETEM is a registered mark for Siemens TTCN Test Manager

TTCN is the Tree and Tabular Combined Notation, see *ISO/IEC DIS 9646-3*

SIETEM combines the advantages of the proven K1197 SDL Test manager with a TTCN subset.

1.1 SIETEM INTEGRATION IN K1197



1.2 ADVANTAGES OF THE 'SIETEM' IMPLEMENTATION

Advantages of the SIETEM:

- The constructs may be mixed with the ones already available on K1197.
  (tested in numerous applications for DBP FTZ,CNET,CSELT,Telecom Australia etc.)
- All the available application programmes with their services may be used.
- Menu driven parameter selection and test case execution
- Hierarchical structure of test suites and unlimited use of subtrees and nesting.
- Verdicts, logs according to ISO 9646 Hierarchical structure of test case and display/ printout of the verdict data.
- Full verdict support (ISO 9646).
- Full test report support (ISO 9646)
- Full PICS, PIXIT support (ISO 9646)
- Default Behaviour (ISO 9646)
- The output functions may be directed to screen, trace, printer .. and combinations.
- Test case statistics
- The trace function reports/logs to capture buffer , screen , disk. The logs may be tra nsferred to disk, screen, printer.
- Provides a soft migration path towards TTCN.

Special supports for:

- Display of received event. (.RX)
- Calling of a subtree may be reported with full short and long name.
- All compiled trees and subtrees are kept in the dictionary and may be called in a tree by name.
  This starts the test manager and runs the tree or tree system.

1.3 TEST SUITE STRUCTURE

The following picture shows the hierarchical structure of a test suite. A single test case may consist of an Initialization sequence (or Preamble), one or more test steps and a Verification sequence (or Postamble):



1.4 SIETEM IN COMPARISON WITH STANDARD NOTATION

X–Notation (verbal notation with arrows)

IUT Tester

Call IS

Test case 1

← A

→ B1

→ B2
Fail

← C

→ D

← E



no subtrees or labels available

K1197 SDL Test Manager

TTCN

```
Test_case1
+IS
!A
 ?B1
   !C
     ?D
       !E
 ?B2
   Fail
```

SIETEM

```
CASE: TEST_CASE1
 +IS
   ! A
    ? B1 1 ?RX
      ! C
       ? D 1 ?RX
         ! E
    ? B2 1 ?RX
      Fail
CASE;
```

+IS should be stored in the common library, especially if it is used in several test cases.

IS = Initialisation sequence

A growing number of specifications of acceptance– and conformance tests is written in TTCN

1.5 SIETEM USED WITH ISDN(ETSI)

Note: This chapter is only important for software with MLFB–Nr.: 8DB11.

1.5.1 GENERAL

The software consist of the ISDN national variant ETSI (ETS 300 102) and the TTCN–tool SIETEM. Both software–parts are located in one (BRI) or in two (PRI) files.

The software will run upon the ISDN–base application Version 3.0 for PRI and BRI.

It can be executed by selecting the item 'Setup' in the applications main menu. Then select 'Conformance tests' and 'other'.

After selecting 'LOAD CONFORMANCE TESTS' it depends on the actual CPU which files will be loaded and executed:

Location	File
CPU1	TST.B1 and TST.B1X
CPU3	TST.B3 and TST.B3X
CPU7	TST.B7
CPU8	TST.B8

The ETSI variant and the SIETEM will be available. To load another ISDN national variant just execute the menu item 'Layer 3 protocol', choose the variant and execute 'LOAD VARIANT'. The system will forget the 'ETSI + SIETEM' software.

IMPORTANT FOR PRI :

When loading a national variant after working with the 'ETSI + SIETEM' software on a PRI–CPU (CPU1, CPU3) the user must execute the following command:

```
ENDRAM DICTLIMIT !
```

Otherwise it is not possible to load or execute any forth–definitions and the system will report ' : ? Dictionary Full! ???? '.

1.5.2 TEST HANDLING

The user may write his own tests using the SIETEM features. It is possible to save these tests within the named files.

Note: changes should be made only on a copy of the disk!

Load the software as described above. Compile the self developed test. Save the hole software (ETSI+SIETEM+Tests) with the following command depending again on the location.

Location	Command
CPU1	" TST.B1X" SAVEX
CPU3	" TST.B3X" SAVEX
CPU7	" TST.B7" SAVEV
CPU8	" TST.B8" SAVEV

The tests will be loaded 'automatically' with the procedure described in the GENERAL part.

When executing the first test the file 'TMTM.Bx' will be loaded. (x is the CPU–number 1,3,7 or 8)

It is a testmanager binary which works as an interface between events (Frames, Timeouts, etc.) and the running test written in TTCN.

This file must be available on any disk or partition when starting the first test.

2 MENU SYSTEM

2.1 PARAMETER AND TEST SELECTION MENU

After loading an application this menu is available.
Parameter setting as well as test case selection and execution is menu driven. The Main Menu item 'CONFORMANCE TEST' leads (press cursor right) to the following submenu:



MENU SELECTION:	
PARAMETER LIST	: List of the PICS and PIXIT variables
TEST SELECTION	: Test Cases tree to be selected and executed
FUNCTION KEYS:	
QUIT_MENU	: Close the menu window
HELP	: Open a help window
COMMAND	: Open FORTH–Interpreter window
VLOG	: Show a list of Verdict of Test Cases wich are finished (See Chapter 2.2.1)
SAVE	: Save the actual values of all PICS/PIXIT parameters
LOAD	: Load previously saved PICS/PIXIT parameters **Note:** Do not use key *DEL* to delete characters of the name of the PICS/PIXIT list! Use key *BS* intead.
VERSION*	: Shows the version of the loaded software in the command window (See Chapter 11.4)

* Only applicable on CCS#7 with SSS–TE

EXAMPLE OF A CONFORMANCE TEST MENU:



2.1.1 PARAMETER MENU

This menu leads into the submenus of several parameter tables. The LOG SELECT table contains SIETEM parameters, which will be described below. The PICS and PIXIT parameter tables are dependent of the actual Conformance Test Suite.



MENU SELECTION:	
LOG_SELECT	: SIETEM Parameters (see chapter 3)
FUNCTION KEYS:	
QUIT_MENU	: Close the menu window
HELP	: Open a help window
COMMAND	: Open FORTH–Interpreter window
SAVE_PARAM	: Save the actual values of the selected PICS/PIXIT parameter
LOAD_PARAM	: Load previously saved PICS/PIXIT parameters

2.1.2 TEST CASE SELECTION MENU

The test selection menu contains submenus of one or more test suites. Each test suite menu consists of several submenus containing the groups, subgroups and cases. Each entry consists of a text concerning the test purpose and the name of the suite/group/subgroup/case. A leading plus means this suite/group/subgroup/case is selected for running, a minus means not. Each test case entry ends with the latest verdict value of this test case. Capital letters mark verdicts, which are the result of the test sequence, small letters mark verdicts, which are assigned by the operator.



FUNCTION KEYS:

QUIT_MENU	: Close the menu window
HELP	: Open a help window
COMMAND	: Open FORTH–Interpreter window
STATIS	: Shows a statistic about the Test Cases wich are finished (See Chapter 2.2.2)
SELECT+–	: Selecting or deselecting of items to be run or not when invoked
SEL_ALL	: Selecting all items of the current suite or group.
SEL_NONE	: Deselecting all items of the current suite or group.
RUN_SEL	: Running the current selected suite, group, subgroup or case, where the green cursor points to.

When a test case / group / suite is deselected with **f5**, the name will be shown in white letters (instead of light blue letters when it is selected) and there is a – instead of a + in front of the name.

2.2 SPECIAL FUNCTIONS

2.2.1 VERDICT LOG (VLOG)

For each test case/subgroup/group/suite an entry will be made in the Verdict Log, if enabled in the LOG SELECT menu. This entry consists of the name and purpose text and the verdict, if the test was executed. Deselected tests are marked as such. Furthermore each operator verdict and operator comment is inserted in the Verdict Log buffer. Also it is possible to get a statistic entry per subgroup, group or suite, if enabled via LOG SELECT parameter.

To get this function see Chapter 2.1.

Status lines dependent on application

```
TEST GROUP     :  Name_of_Testgroup                        92/ 8/10 15:39:30

TEST CASE      :  Name_of_Testcase                         92/ 8/10 15:39:31
VERDICT        :  PASS
TEST CASE      :  Name_of_Testcase                         92/ 8/10 15:39:32
                  DESELECTED
TEST CASE      :  Name_of_Testcase                         92/ 8/10 15:39:33
VERDICT        :  FAIL
TEST GROUP     :  Name_of_Testgroup                        92/ 8/10 15:39:34
VERDICT        :  FAIL
STATISTICS     :  DESELECTED TEST CASES : 1
                  SELECTED   TEST CASES : 2

                    SYSTEM VERDICTS          OPERATOR VERDICTS*
                    PASS    : 1              PASS    : 0
                    FAIL    : 1              FAIL    : 0
                    INCONC  : 0              INCONC  : 0

OK-M
OK-M
```

1	2	3	4 QUIT_VLOG	5 PRINT	6 STARTLINE	7 END_LINE	8 ALL LINES

FUNCTION KEYS:

QUIT_VLOG	: Close the VLOG window
PRINT	: Print the contents of the Verdict Log.
STARTLINE	: Mark the line at the current cursor position as first line to be printed.
END_LINE	: Mark the line at the current cursor position to be printed as last line.
ALL_LINES	: Mark the whole Verdict Log buffer to be printed.

Inside this menu the cursor keys can be used to display and scroll the Verdict Log buffer contents.

* This function is not available on CCS#7

2.2.2 STATISTICS

The statistic function of a suite/group/subgroup gives an overview of the number of selected and deselected test cases. For the selected test cases also an overview of verdicts and operator verdicts is shown.

To get this function see Chapter 2.1.2.



FUNCTION KEYS:

QUIT_STAT : Close the STATISTICS window

* This function is not available on CCS#7

3 SIETEM PARAMETERS

To change the values of the SIETEM parameters, please move with the cursor keys to the following menu:



Then move right with the cursor to following menu:



The standard access to PICS and PIXIT tables is embedded in the menu system. Selecting the Parameter (PICS/PIXIT) menu pages displays the parameters with its actual values as contained in the variables. That is the default setup. If a parameter has to be changed, it has to be selected on the menu page via cursor keys.

3.1 LOG_SELECT

LOG SELECTION PARAMETERS

3.1.1 TEST ENVIROMENT

HEADER–STRINGS*

Possible Values: ON **OFF**
Meaning:
Prints a LOG–Header.
ON: Following strings will be print as header of the LOG–file.
OFF: Following strings will not be print as header of the LOG–file.

TEST–LAB–STRING*

Meaning:
Prints information about the Test laboratory in the LOG–file.

CLIENT–STRING*

Meaning:
Prints information about the client (tester) in the LOG–file.

SUT–STRING*

Meaning:
Prints information about the 'System Under Test' in the LOG–file.

Note: The strings shall not contain spaces (0x20)!

3.1.2 LOG REPORT PARAMETERS

LOG

Possible values: **LOG#OFF**
LOG#CASE
Meaning:
No LOG–REPORT is written, or after each test case the LOG–REPORT is written.

LOGHEAD–PARAMLIST–OUTPUT

Possible values: **YES** NO
Meaning:
If YES is used, the complete actual status of all parameter/PICS/PIXIT lists is output at the start of a test log.

* Only available for CCS#7-Application

3.1.3 DISK LOG PARAMETERS

LOG–DRIVE

Possible values: #DR0
#DR1
#WD0
#WD1
#WD2
#WD3
#WD4
#WD5
#WD6
#WD7

Meaning:
Drive the DISK–LOG files should be written.
Note:
Use no **DD**–(Double Density)–Disks!

DISKLOG_PASS

Possible values: **LOG#OFF**
LOG#SHORT
LOG#LONG

Meaning:
Nothing / name and verdict / name, trace and verdict are stored to disk, where test cases name is file name in LOG–REPORT.

DISKLOG_FAIL

Possible values: **LOG#OFF**
LOG#SHORT
LOG#LONG

Meaning:
Nothing / name and verdict / name, trace and verdict are stored to disk, where test cases name is file name in LOG–REPORT.

DISKLOG_INCONC

Possible values: **LOG#OFF**
LOG#SHORT
LOG#LONG

Meaning:
Nothing / name and verdict / name, trace and verdict are stored to disk, where test cases name is file name in LOG–REPORT.

ONE_FILE_PER_CASE/GROUP

Possible Values: YES **NO**
Meaning:
Applies only for disk log.
NO: The complete suite or part of it is logged into one file.
YES: Each case or group log is put into a separate file. Only the long format creates a file.

3.1.4 PRINT LOG PARAMETERS

PRINTLOG_PASS

Possible values: **LOG#OFF**
LOG#SHORT
LOG#LONG

Meaning:
Nothing / name and verdict / name, trace and verdict are written in LOG–REPORT, in case the test ends with verdict "PASS".

PRINTLOG_FAIL

Possible values: **LOG#OFF**
LOG#SHORT
LOG#LONG

Meaning:
Nothing / name and verdict / name, trace and verdict are written in LOG–REPORT, in case the test ends with verdict "FAIL".

PRINTLOG_INCONC

Possible values: **LOG#OFF**
LOG#SHORT
LOG#LONG

Meaning:
Nothing / name and verdict / name, trace and verdict are written in LOG–REPORT, in case the test ends with verdict "INCONC".

3.1.4.1 REPORT PARAMETER FOR X.25

PRINT–REPORT–TYPE

Possible values: **SHORT#REPORT**
COMPLETE#REPORT
HEX#REPORT
CHAR#REPORT

Meaning:
With this parameter, different report types may be selected for screen display of layer 4 events and for printout. The screen report type is selected via monitor/ report menu. The print log report type is taken from this parameter.

3.1.4.2 REPORT PARAMETERS FOR ISDN

PRINT-L3-REPORT-MODE

Possible values: **L3SHORT#MODE**
L3MEDIUM1#MODE
L3MEDIUM2#MODE
L3COMPLETE#MODE

Meaning:
With this parameter, different report types may be selected for screen display of layer 3 events and for printout. The screen report type is selected via monitor/ report menu. The print log report type is taken from this parameter.

PRINT-L3-REPORT-TYPE

Possible values: L3_NONE#REPORT
L3_MNEMONIC#REPORT
L3_HEX#REPORT
L3_CHAR#REPORT

Meaning:
With this parameter, different report types may be selected for screen display of layer 3 events and for printout. The screen report type is selected via monitor/ report menu. The print log report type is taken from this parameter.

PRINT-L2-REPORT-TYPE

Possible values: L2_NONE#REPORT
L2_COMPLETE#REPORT
L2_HEX#REPORT
L2_CHAR#REPORT
L2_SHORT#REPORT

Meaning:
With this parameter, different report types may be selected for screen display of layer 2 events and for printout. The screen report type is selected via monitor/ report menu. The print log report type is taken from this parameter.

PRINT-L1-REPORT-TYPE

Possible values: L1_NONE#REPORT
L1_COMPLETE#REPORT
L1_SHORT#REPORT

Meaning:
With this parameter, different report types may be selected for screen display of layer 1 events and for printout. The screen report type is selected via monitor/ report menu. The print log report type is taken from this parameter.

3.1.4.3 REPORT PARAMETERS FOR CCS#7

PRINT-L4REPORT-TYPE

Possible values: **PRINT#OFF**
PRINT#SHRT
PRINT#HEX
PRINT#CHAR
PRINT#COMP
PRINT#MED
PRINT#MED2
PRINT#MED3
PRINT#MED4

Meaning:
With this parameter, different report types may be selected for screen display and for printout. The screen report type is selected via monitor/ report menu. The print log report type is taken from this parameter.

PRINT-TCAPREP-TYPE*

Possible values: **PRINT#OFF**
PRINT#SHRT
PRINT#HEX
PRINT#CHAR
PRINT#COMP
PRINT#MED
PRINT#MED2
PRINT#MED3
PRINT#MED4
PRINT#MED5

Meaning:
With this parameter, different report types may be selected for screen display and for printout. The screen report type is selected via monitor/ report menu. The print log report type is taken from this parameter.

PRINT-SCCPREP-TYPE

Possible values: **PRINT#OFF**
PRINT#SHRT
PRINT#HEX
PRINT#CHAR
PRINT#COMP
PRINT#MED
PRINT#MED2
PRINT#MED3
PRINT#MED4

Meaning:
With this parameter, different report types may be selected for screen display of SCCP message and for printout. The screen report type is selected via monitor/ report menu. The print log report type is taken from this parameter.

PRINT-L3REPORT-TYPE

Possible values: **PRINT#OFF**
PRINT#SHRT
PRINT#HEX

* Only available if TCAP-User Part is used

PRINT#CHAR
PRINT#COMP
PRINT#MED
PRINT#MED2
PRINT#MED3
PRINT#MED4

Meaning:
With this parameter, different report types may be selected for screen display and for printout. The screen report type is selected via monitor/ report menu. The print log report type is taken from this parameter.

PRINT-L2REPORT-TYPE

Possible values: **PRINT#OFF**

PRINT#SHRT
PRINT#HEX
PRINT#CHAR
PRINT#COMP
PRINT#MED
PRINT#MED2
PRINT#MED3
PRINT#MED4

Meaning:
With this parameter, different report types may be selected for screen display and for printout. The screen report type is selected via monitor/ report menu. The print log report type is taken from this parameter.

PRINT-L1REPORT-TYPE

Possible values: **PRINT#OFF**

PRINT#SHRT
PRINT#COMP

Meaning:
With this parameter, different report types may be selected for screen display and for printout. The screen report type is selected via monitor/ report menu. The print log report type is taken from this parameter.

3.1.5 TEST SUITE EXECUTION CONTROL PARAMETERS

RUN–SELECTION–MODE

Possible values: **ALL** ONLY–CASES–WITH–VERDICT<>PASS
Meaning:
IF ONLY–CASES–WITH–VERDICT<>PASS is used, only those test cases will be executed, which have no PASS Verdict got before.

RESTRICTED_CASES/GROUPS/SUITES

Possible values: **ON** OFF
Meaning:
If OFF is used, all the invoked cases are run, no matter if they are selected (appear green in the case selection menu) or not. If ON is used, only the selected (green) test cases/groups/ subgroups/suites are run.

REGULATORY_CAMPAIGN

Possible values: **ON** OFF
Meaning:
If ON is used, only the PICS dependent selected test cases/groups/ subgroups/suites are or can be enabled.So it is assured, that only those test cases, that make sense in the light of the PICS, are run.

WAIT_TIME_AFTER_CASE

Possible values: [0 .. 10000]
Meaning:
Time between two running test cases in a group, subgroup or suite, where you can check the last test, or where you can type in FORTH commands.

3.1.6 LOG OUTPUT PARAMETERS

CASE_SEPARATOR

Possible values: **HORIZONTAL-BAR**
HORIZONTAL=BAR
FORM#FEED
OFF

Meaning:
Line Separator (------ , ====== or FF) for printer in LOG-REPORT.

GROUP_SEPARATOR

Possible values: **HORIZONTAL=BAR**
FORM#FEED
OFF
HORIZONTAL-BAR

Meaning:
Line Separator (------ , ====== or FF) for printer in LOG-REPORT.

CGS_HEADER_DATE

Possible values: **ON** OFF

Meaning:
If ON is used, each test case/group/.. in the log will output the date. If there is sufficient space on the line, also the time of day is included.

LINE_AFTER_VERDICT

Possible values: **ON** OFF

Meaning:
If ON is used, the verdict capture entry will be followed by a new line.

3.1.7 VERDICT LOG PARAMETERS

VERDICT–LOG

Possible values: **YES** NO
Meaning:
If YES is used, the Verdict Log will be allocated

VERDICT–LOG–PASS–IMMED

Possible values: YES **NO**
Meaning:
If YES is used, the respective verdicts are written immediately to the Verdict Log

VERDICT–LOG–FAIL–IMMED

Possible values: YES **NO**
Meaning:
If YES is used, the respective verdicts are written immediately to the Verdict Log

VERDICT–LOG–INCONC–IMMED

Possible values: YES **NO**
Meaning:
If YES is used, the respective verdicts are written immediately to the Verdict Log

VERDICT–STATISTICS–SUBGROUP

Possible values: **YES** NO
Meaning:
If YES is used, a statistic of the respective suite/group/subgroup is inserted in the Verdict Log.

VERDICT–STATISTICS–GROUP

Possible values: **YES** NO
Meaning:
If YES is used, a statistic of the respective suite/group/subgroup is inserted in the Verdict Log.

VERDICT–STATISTICS–SUITE

Possible values: **YES** NO
Meaning:
If YES is used, a statistic of the respective suite/group/subgroup is inserted in the Verdict Log.

3.1.8 PRELLIMINARY VERDICT PARAMETERS

PASS–IMMED–DISPLAY

Possible values: **NO** YES

Meaning:

If YES is used, the respective verdicts are output immediately. If NO is selected, the verdicts appear only as final verdicts at the end of the test case/subgroup/group/suite.

FAIL–IMMED–DISPLAY

Possible values: NO **YES**

Meaning:

If YES is used, the respective verdicts are output immediately. If NO is selected, the verdicts appear only as final verdicts at the end of the test case/subgroup/group/suite.

INCONC–IMMED–DISPLAY

Possible values: NO **YES**

Meaning:

If YES is used, the respective verdicts are output immediately. If NO is selected, the verdicts appear only as final verdicts at the end of the test case/subgroup/group/suite.

4 SOFTWARE INTERFACES TO MENU SYSTEM

4.1 INTERFACE TO BASIC–SOFTWARE

The interface between SIETEM and the Basic–Application consists of the DOER word **<CONF_TEST>** which will be executed when the menu item CONFORMANCE TEST will be called.

In SIETEM a 'MAKE' to <CONF_TEST> will be done, so the first SIETEM menu appears by calling the menu item CONFORMANCE TEST.



4.2 INTERFACE TO TEST CASES.

The interface between SIETEM and the test cases consist of the definition of:

STEP	and	**PICSL**
CASE		
SUBGROUP		
GROUP		
SUITE		

The output of the names of the testcases and other texts will be put into menus. The layout of the menus is determined, but the size of it will be set flexible during compiling time of the test cases. It depends on the number of SUITE, GROUP, .. , PICSL definitions.



For more information see chapters 6 and 10 .

5 INDENTATION COMPILER

ON / OFF ATCM switches the compiler on / off

This compiler changes, when switched on, the behaviour of the normal FORTH compiler. The FORTH compiler becomes indentation–sensitive, as necessary for TTCN.
It reacts on (column indented) **?** symbols, followed by a space, at the beginning of a line.

With this possibility of identation you can create sequential parts and alternatives of receiving messages in a short and well structured way:

Sequential usage:

```
! Send_msg1
   ? Receive_msg2
      ! Send_msg3
         ? Receive_msg4
              .
              .
```

Meaning:

First send message1, then wait for receiving message2, after that send message3 and wait for receiving message4, and so on.

Usage of alternatives:

```
! Send_msg1
   ? Receive_msg2
        ! Action2_1
   ? Receive_msg3
        ! Action3_1
   ? Receive_msg4
        ! Action4_1
              .
              .
              .
```

Meaning:

First send message1, then wait for receiving message 2 or message 3 or message 4.
When, for example, message3 is received, the Action3_1 will be done. In this case Action2_1 and Action4_1 **never** will be executed.

Note: While 'ON ATCM' do **not** use any kind of colours or tabs in the editor of the K1197 !

? (--)
TTCN Receive Operator

! (--)
TTCN Send Operator

Note: The behaviour of the word '!' depends on the ATCM mode:
OFF ATCM:
! : FORTH 'store' Operator
ON ATCM:
! : TTCN 'Send' Operator
LI: FORTH 'store' Operator

IF? **(flag --)**

'IF' construct, depending on the occurrence of '!' or '?'.
When after '?', execute **IF part**
When after '!', execute **ELSE part.**

5.1 FEATURES OF COMPILER

There are some special features according to ISO/IEC–DIS 9464–3 used in SIETEM.

5.1.1 TEST STEP ATTACHMENT

Some sequences of sending and receiving messages will be used in several test cases. For this usage, you can create a test step (see chapter 6.1). This test step will then be called by the test cases:



The name of a test step should always begin with a '+', then an attached test step looks like defined in ISO/IEC–DIS 9464–3.

5.1.2 DEFAULT BEHAVIOUR

A TTCN test specification shall specify alternative behaviour for **every** possible event. It often happens that in a behaviour tree every sequence of alternatives ends in the same behaviour. This behaviour may be 'factored out' as default behaviour to this tree. Such default behaviour descriptions are located in the global defaults library.

In many cases the default construct will be used to emphasize a set of 'interesting' paths through a test by declaring the less interesting common alternatives as default behaviour.

DEFAULT ATTACHMENT:



SPECIAL WORDS:

DEFAULT: (--)
Start of a default definition
Usage:
```
DEFAULT: name_of_default
   .
   .
DEFAULT;
```

DEFAULT; (--)
End of a default definition

DEFAULT= (--)
Identifies Default structure for all following test cases
Usage: `DEFAULT= name_of_default`

Note: To switch off default behaviour type:
`DEFAULT= NOTHING`

Example:

```
ON ATCM
DEFAULT: Name_of_DEFAULT-part
         ? . . .
         .
         .
         .
DEFAULT;

DEFAULT= Name_of_DEFAULT-part

OFF ATCM
```

5.1.3 EXIT TESTSTEP / CASE

In case of a final FAIL or an unexpected event in a test step / case it makes no sense to go on. So you can break off the test step / case and leave it.

Note: Use these words only in a test case / step, usually after calling the postamble or in default behaviour!

ULTIMATE_FAIL **(--)**
Outputs the name of the test step or contraint where the test case is broken down.

!SHUTDOWN **(--)**
Initiates shutdown of a test case / step.

?SHUTDOWN **(-- flag)**
Shutdown the test case / step and ends all running emulations in a correct way.
This word should always be called after a **?** in receiving line.

EXIT-> **(--)**
Leaves the test step / case in a correct manner.

Example:

```
ON ATCM
CASE: Case_name
          .
          .         .
       ? Timer_No ?TIMER
           ULTIMATE_FAIL
           (FAIL)
           !SHUTDOWN
             ? ?SHUTDOWN
               EXIT->
CASE;
OFF ATCM
```

5.1.4 RESCAN

RESCAN causes SIETEM on an event that did not match the event list nor the default behaviour's event list to drop the event, wait for a new one and start again the event matching process at the beginning (first '?' in column) of the current level. (See DIS ISO 9646)

YES_LOOP! **(--)**
Enables Rescan. (Default value)

NO_LOOP! **(--)**
Disables Rescan.

5.1.5 REMAIN

REMAIN enables to jump backwards in test steps / cases.
'REMAIN' is identical to the 'RETURN' statement of the further ISO/IEC–IS 9464–3.

Note: Use this feature only with caution!
It destroys the sequential structure of a test case.
Please avoid this feature, if possible!

REMAIN **(– –)**
Compiler jumps back to the first '?' in the column REMAIN was called.

REMAIN_DEFAULT **(– –)**
Like REMAIN, but used in ' DEFAULT'–Construct.

Example:



In this example the message3 was received, so the test case will remain in this column and start again with waiting for a message.

6 TEST STEP, CASE, GROUP, SUITE

The structure of a conformance test suite is mainly, according to ISO 9646:



But even totally flat structures with only cases in a suite are possible.

Note: Recursive calls between suite–group–case are **not** allowed!

The number of entries is unlimited for GROUP, SUBGROUP and CASE. The limit for SUITE is 10 entries. STEP should not be used in the conformance test suite, but should be only called in a test case.

Each test case is responsible for correct reaction on verdicts.
If a partial or preliminary FAIL is encountered, this should lead to a correct sequence:

not to issue send commands that are thought only in case of PASS
run the correct postambles if necessary for recovery
leave the test case in orderly fashion
(See chapter 5.1.2)

The next test case in suite has not to be disturbed!

Each test group, suite, subgroup and case (e.g. in CASE: and CASE;) contains two 'DOER' constructs at the begin and end: (see Chapter 11.4)

The DOERs may contain:

Print/Disk log control, depending on result
Identification frame sending
Host handshake

HOW TO CREATE A NEW TEST SUITE IN THE TEST SELECTION MENU:

1. Define the **test cases** and **steps**!
2. Create a tree structure of all test cases.
3. Attach your suites to the 'Test Selection' Menu.

6.1 DEFINE TEST CASES / STEPS

STEP: (--)
Starts a test step definition.
Example: `STEP: STEP_name`

STEP; (--)
Ends a test step definition

CASE: (--)
Starts a test case definition.
Example: `CASE: CASE_name`

CASE; (--)
Ends a test case definition

-" **(-- string address)**
Compile string into dictionary.
String definition for the objects and test cases, groups, subgroups, and suites.
Example : -" comment " ,
The difference to the normal quote " is, that the literal buffer is not used
but the string is compiled into dictionary to stay accessible.

Note: Don't forget the comma following the long name string!

A test step may look like:

```
ON ATCM                                          ( switch indentation compiler on)
        -" This is a long name for STEP1 " ,
        STEP:    +STEP1                          ( test step start&name )
                    ! Send_msg1
                          ? Receive_msg2
                                  Action1
                             ! Send_msg3
                                  ? Receive_msg4
                                          Action2
        STEP;                                    ( test step subtree end )
OFF ATCM                                         ( switch indentation compiler off )
```

A test case may look like:

```
ON ATCM                                          ( switch indentation compiler on)
        -" Test case for purpose ... " ,
```

```
        CASE:    CASE1                          ( test case start and name)
                 +STEP1
                          ?  Receive_msg1
                                 PASS
                          ?  Receive_msg2
                                 INCONC
                          ?  Receive_msg3
                                 FAIL
        CASE;                                   ( test case end )
OFF ATCM                                        ( switch indentation compiler off )
```

The called test step +STEP1 in the test case will be expanded, how desribed in chapter 5.1.1.

6.2 CREATE SIETEM TREE STRUCTURE

GROUP: (--)
Starts a test group definition.
Example: `GROUP:` GROUP_name

GROUP; (--)
Ends a test group definition

SUBGROUP: (--)
Starts a test subgroup definition.
Example: `SUBGROUP:` SUBGROUP_name

SUBGROUP; (--)
Ends a test subgroup definition

SUITE: (--)
Starts a test suite definition.
Example: `SUITE:` SUITE_name

SUITE; (--)
Ends a test suite definition

Example:

```
ON ATCM
      -" long name" ,
      SUBGROUP: SUBGROUP1
          CASE1
      SUBGROUP;
OFF ATCM

ON ATCM
      -" long name" ,
      GROUP: GROUP1
          SUBGROUP1
      GROUP;
OFF ATCM

ON ATCM
      -" long name" ,
      SUITE: SUITE1
          GROUP1
      SUITE;
OFF ATCM
```

6.3 ATTACH THE TEST SUITE TO THE MENU SYSTEM

There are 10 slots for TEST SUITEs. To attach a test suite at position 2, type:

```
2  SET_SUITE  SUITE_name
```

SET_SUITE sets the named test suite definition into the selection menu ' TEST SELECTION' at the given slot. The 10 slots are numbered from 1 to 10.

SET_SUITE **(# of slot --)**
The slots are filled initially with EXIT. (1...10 SET_SUITE EXIT). The EXIT is an indication for the display not to show the line and stop.

AUTO_SET_SUITE **(--)**
Like SET_SUITE, but automatically creation of next slot number.

7 CASE SELECTION TOOL

Now, the structure for selecting and deselecting of test cases, subgroups, groups and suites (CGS) will be decsribed.

The final decision, if a CGS is run, is found with the word SELECTED?:

SELECTED? **(PFA of CGS -- FLAG)**
Is the CGS selected according to the 'SEL-BIT-TABLE'.
SELECTED? uses a truth table for the decision.

KARNAUGH TABLE for SELECTED?:



In textual form, the setting of '1' in this combination means:

SELECTED? = (REGULATORY AND (SEL? OR NOT RESTRICTED) AND NOT LOCKED)
OR
(NOT REGULATORY AND (SEL? OR NOT RESTRICTED))



Usually, 'SELECTED?' has to be defined with IF-CLAUSES, but using the KARNAUGH-table is a much shorter form!

To input this table there are two variables

RESTRICTED_CASES/GROUPS/SUITES

REGULATORY_CAMPAIGN

and a table definition:

```
0X01010101  VARIABLE SEL-BIT-TABLE
0X00010001 ,
0X01010000 ,
0X00010000 ,
```

Note: When e.g. a group is deselected, it does not run. That does not mean, that all the contained cases are deselected. When the deselected group is entered, it is still possible to run the selected test cases if expressively wanted.

SOME WORDS:

Here are some words to change select and lock bit of a CGS:

SELECT_CGSP **(PFA OF CGS --)**
set select bit to 1

SELECT_CGS **(--)**
set select bit to 1
Usage: `SELECT_CGS SUITE_name`

DESELECT_CGSP **(PFA OF CGS --)**
set select bit to 0

DESELECT_CGS **(--)**
set select bit to 0
Usage: `DESELECT_CGS SUITE_name`

LOCK_SELECTP **(PFA OF CGS --)**
set the lock bit to 1
Usage: `' SUITE_name LOCK_SELECTP`

LOCK_SELECT **(--)**
set the lock bit to 1
Usage: `LOCK_SELECT SUITE_name`

UNLOCK_SELECTP **(PFA OF CGS --)**
set the lock bit to 0
Usage: `' SUITE_name LOCK_SELECTP`

UNLOCK_SELECT **(--)**
set the lock bit to 0
Usage: `LOCK_SELECT SUITE_name`

SEL? **(PFA -- FLAG)**
is the cgs's select bit on ? PFA is the respective CGS's parameter field address, as may be obtained with '

LOCKED? **(PFA -- FLAG)**
is the CGS's lock bit on ?

CURRENT-CGS-PFA **(-- PFA)**
Gives the PFA of the currently running CGS.

CURR_CGS_SEL? **(-- FLAG)**
is the running case/group/suite selected ?

8 VERDICTS

At the end of each test step / case / subgroup / group / suite, the resulting verdict is transferred to the next higher structure, using the verdict rules from ISO 9646.
Then the name is displayed/recorded together with the verdict.

8.1 VERDICT WORDS

According to ISO 9646 there are final verdicts and preliminary verdicts.

Final verdicts:

PASS (--)
Give pass verdict, to trace

P (--)
Short form of PASS

The TCAP word **P** had to be redefined in SIETEM! Instead of **P** the word **PD** can be used. The word 'P' in SIETEM is the abbreviation of 'PASS'.

INCONC (--)
Inconclusive verdict

INC (--)
Short form of INCONC

FAIL (--)
Fail verdict

F (--)
Short form of FAIL

ERROR_VERDICT (--)
ERROR verdict in case of a system error

Preliminary verdicts:

(PASS)	**(INCONC)**	**(FAIL)**
(P)	**(I)**	**(F)**

Word used for constructs, depending on verdicts:

?PASS (-- **flag**)
Delivers true if verdict = PASS

VERDICT? **(pfa -- verdict number)**
Which verdict does a test case / group / suite have?
The verdict number means:
0 = NONE
1 = PASS
2 = INCONC
4 = FAIL
8 = ERROR of system

8.2 TEST RUN

After starting the test suite/group/subgroup or the test case on which the cursor is positioned with **RUN_SEL (F8)**, if selected in the menu, the text at the beginning of each test suite/test group/test case is marked blue on the screen followed by a detailed description of the started test part.
At the end of each test case the same presentation appears, followed by one of the possible verdicts PASS, FAIL or INCONC.

There is the following colour assignement:

PASS marked blue
FAIL marked red
INCONC marked yellow

At the end of a test group or a test suite a global verdict is added in the same way. In the test run, temporary verdicts appear in brackets with the same colour assignement.

9 TEST SUITE EXAMPLE

This example running on CCS#7 shows a test suite with test groups / subgroups containing test cases, which calls test steps and the used utility words:

Utilities:

```
47 CONSTANT WAIT_FOR_PAR_TIMER
48 CONSTANT Maintenance-TIMER
0  VARIABLE DeleteIMSI1.IID     ( Local Variable for Invoke ID )
0  VARIABLE DeleteIMSI1.IMSI    ( Local Variable for IMSI )
0  VARIABLE PAR_COUNTER



: WAIT_FOR_PARS  ( Number of parall. parts -- flag )
  1
  DOCASE
     CASE 1 1 ?TM_IPC
                     { PAR_COUNTER 1+
                             .
                             .
                             .
                     }
     CASE 2 2 ?TM_IPC
                     { PAR_COUNTER 2+
                             .
                             .
                             .
                     }
          .
          .
          .
  ENDCASE

    .
    .
    .
;
```

PCO – Point of Control and Observation (See ISO/IEC–DIS 9464–3):

```
: HLR_MAP-D ( -- flag ) ( RECEIVE ) ( EDIT_SCCP_TCAP had to be )
            ( -- )      ( SEND )    ( done before )
  IF?       ( RECEIVING ? )
    ?LINK 1 =                   ( CHECK IF LINK CORRECT - HLR )
    IF
      0X307E ?DUP               ( SPC for HLR )
      IF                        ( CHECK DPC IF <> 0 )
        ?MSU_TO_DPC
        FALSE->                 ( See Chapter 11.1 )
      THEN
          .
          .
      #GSM_SCCP #SCCP_UDT ?RX_SU      ( IS IT SCCP UNIT DATA ? )
          FALSE->
      SCCP_CLD_SSN P@                 ( Check if called SSN = HLR  )
          FALSE->
            6 =                       ( #SSN for HLR )
          FALSE->
          .
          .
          .
       SCCP_DATA_DATA P@      ( Check if DATA parameter is present )
          FALSE-> DROP
          .
       ( TCAP emulation will be called )
          .
          .
    ELSE
        V." Message for other LINK received in PCO: HLR_MAP-D" VCR
          .
          .
          .
    ENDIF
  ELSE     ( SENDING )
          .
    ( TCAP emulation will be called )
          .
          .
    SEND_SCCP_TCAP
  ENDIF
;
```

This definition of a PCO explicitly handles I/O and lower layer emulation. It checks received messages if they fit in this PCO. When messages are sent via this PCO lower layer support is automatically included.

Constraints (See ISO/IEC–DIS 9464–3):

```
: DISUP_REL                    ( flag -- flag )
  IF
    #D1ISUP #DI_REL ?RX_SU
        FALSE->
          .
          .
          .
    1
  ELSE
    0
  ENDIF
;

: TcResultLInd[DID2,I]         ( flag -- flag )
  IF
     #TCAP #MSG_END ?TCAP_SU
           FALSE->
          .
          .
          .
     INVOKE_ID  T@
           FALSE->
        DeleteIMSI1.IID @ =
           FALSE->
     RRL_COMPONENT T@
           FALSE-> DROP
     1
  ELSE
     0
  ENDIF
;
```

PREAMBLE:

```
ON ATCM

STEP: +PREAMBLE
          .
          .
       ( Initialize Links )
       ( Load Pool messages )
          .
          .

STEP;

OFF ATCM
```

POSTAMBLE:

```
ON ATCM

STEP: +POSTAMBLE
        .
        .
      ( Release all pending dialogues and disconnect emulations )
        .
        .
        .
      !SHUTDOWN
        .
STEP;

OFF ATCM
```

Default behaviour:

```
ON ATCM

DEFAULT: TESTEND
      ? Maintenance-TIMER ?TM_TIMER
         ULTIMATE_FAIL
         (FAIL)
         +POSTAMBLE
           ? ?SHUTDOWN
             EXIT->
        .
        .

      ? MSC1_ISUP DISUP_REL
         REMAIN_DEFAULT
        .
        .
        .

      ? BSS1_BSSAP
         ULTIMATE_FAIL
         (FAIL)
         +POSTAMBLE
           ? ?SHUTDOWN
             EXIT->
        .
        .
        .

      ? ?SHUTDOWN
         (FAIL)
         EXIT->
DEFAULT;

DEFAULT= TESTEND

OFF ATCM
```

Test step:

```
ON ATCM

STEP: +DeleteIMSI1
      " TcB-INV_CancLoc" EDIT_SCCP_TCAP        ( GET MESSAGE FROM POOL)
         .
         .
      ! HLR_MAP-D
         .
         .
         .

        Maintenance-TIMER 100 START_TM_TIMER
            ?   HLR_MAP-D  TcResultLInd[DID2,I]
                Maintenance-TIMER STOP_TM_TIMER
                (PASS)
                   .
                   .
                   .
            ?   HLR_MAP-D
                Maintenance-TIMER STOP_TM_TIMER
                (INCONC)
STEP;

OFF ATCM
```

Test cases:

```
ON ATCM

-" LUIR/CT/NormalUpdatewithIMSI" ,
CASE: 2.1.0.1
      +PREAMBLE
        " 262011500000001"  DeleteIMSI1.IMSI !STRING
        +DeleteIMSI1
         .
         .
         .
CASE;

OFF ATCM
```

```
ON ATCM

STEP: 2.1.1.2.1.2.PAR1
          .
          .
          .
       ! 1 0 TM_IPC_SEND              ( Send coordination message CM to
                                        coordinatin point CP )
STEP;


STEP: 2.1.1.2.1.2.PAR2
          .
          .
          .
      ! 2 0 TM_IPC_SEND               ( Send coordination message CM to
                                        coordinatin point CP )

STEP;


-" LUIR/NB/AUT/DVSP/4AUTHsets" ,
CASE: 2.1.1.2.1.2
     +PREAMBLE
          imsi1  DeleteIMSI1.IMSI !STRING
        +DeleteIMSI1
            .
            .
            .
                    1 ' 2.1.1.2.1.2.PAR1 ->TM  ( Starts two parallel parts )
                    2 ' 2.1.1.2.1.2.PAR2 ->TM  ( See Chapter 12.2 )
                    WAIT_FOR_PAR_TIMER 300 START_TM_TIMER
                      ? 2 WAIT_FOR_PARS        ( Wait for end message of both
                                                 parallel parts )
                            WAIT_FOR_PAR_TIMER STOP_TM_TIMER
                            (PASS)
                      ? WAIT_FOR_PARS_TIMER ?TM_TIMER
                            (FAIL)
                      .
                      .
                      .
                      .

CASE;

OFF ATCM
```

Test suite:

```
ON ATCM

-" LUIR/Capability Tests (CT)" ,
GROUP: 2.1.0
       2.1.0.1
GROUP;

-" LUIR/NB/Initial Message (IM)" ,
GROUP: 2.1.1.1
        .
        .
        .
GROUP;

-" LUIR/NB/AUT/DataVarSendP(DVSP)" ,
SUBGROUP: 2.1.1.2.1
          2.1.1.2.1.2
        .
        .
        .
SUBGROUP;

-" LUIR/NB/Authentication (AUT)" ,
GROUP: 2.1.1.2
       2.1.1.2.1
GROUP;

-" LUIR/NB/Identification (ID)" ,
GROUP: 2.1.1.4
        .
        .
        .
GROUP;

-" LUIR/Normal Behaviour (NB)" ,
GROUP: 2.1.1
       2.1.1.1
       2.1.1.2
       2.1.1.4
GROUP;

-" LU/Initial Registration (LUIR)" ,
GROUP: 2.1
       2.1.0
       2.1.1
        .
        .
        .
GROUP;
```

```
-" LU/IMSI known in VLR (LUIK)" ,
GROUP: 2.2
       .
       .
       .
GROUP;

-" LU/IMSI known in PVLR (LUPV)" ,
GROUP: 2.3
       .
       .
       .
GROUP;

-" Location Update" ,
SUITE: LU
        2.1
        2.2
        2.3
SUITE;

AUTO_SET_SUITE LU

OFF ATCM
```

10 PICS/PIXIT PARAMETERS

PICS / PIXIT Parameters are objects used like variables, they will be needed to initialize the test cases surrounding.
The advantage of them is the possibility to change the values via menu system!

The objects contain some methods (functions to be performed on object data) and some data. There are several classes: enumerated variables, decimal number variables, hex strings, data frames etc.

The environment looks as follows:



HOW TO CREATE PICS/PIXIT PARAMETERS:

1. Define the **objects** with the default values!

2. Create a new menu entry (**PICS–List**)!

10.1 DEFINE PICS/PIXIT–OBJECTS

ENUM_PICS Definition for Enumerated PICS/PIXIT Object.

Usage:
1.) Number of parameters (Constants)
2.) Default_value
3.) **ENUM_PICS**
4.) Name of PICS/PIXIT parameter
5.) List of Constants

Example:
```
2  ON  ENUM_PICS  RESTRICTED_CASES/GROUPS/SUITES   ON  OFF
```

ENUM_PARAM Definition for enumerated PICS/PIXIT Object to use an already defined Variable.

Usage:
1.) Number of parameters (Constants)
2.) Name of Variable
3.) **ENUM_PARAM**
4.) Name of PICS/PIXIT parameter
5.) List of Constants

DECIMAL_PICS Definition for Decimal Number PICS/PIXIT Object

Usage:
1.) –" Prompt String"
2.) Lower_bound (positive 31bit number 0.. 2x10 ** 9)
3.) Upper_bound (positive 31bit number 0.. 2x10 ** 9)
4.) Default_value
5.) **DECIMAL_PICS**
6.) Name of PICS/PIXIT parameter

Example:
```
–" INPUT TIME IN TENTH OF SECONDS " 0 10000
0 DECIMAL_PICS WAIT_TIME_AFTER_CASE
```

DECIMAL_PARAM Definition for Decimal Number PICS/PIXIT Object to use an already defined variable.

Usage:
1.) –" Prompt String"
2.) Lower_bound (positive 31bit number 0.. 2x10 ** 9)
3.) Upper_bound (positive 31bit number 0.. 2x10 ** 9)
4.) **DECIMAL_PARAM**
5.) Name of PICS/PIXIT parameter

HEXSTRING_PICS Definition for Hex String Pics/Pixit Object.

Usage:
1.) –" Prompt String"
2.) Maximal length (Maximal Size for input strings: 80 characters.)
3.) **HEXSTRING_PICS**
4.) Name of PICS/PIXIT parameter
5.) Initial HEX string"

Example:

```
-" INPUT HEX STRING. 3 OCTETS: 1. A-H, 2. Timeslot, 3. I-K"
3 HEXSTRING_PICS circ1 010203"
```

Note: Do not insert more spaces or returns between 'HEXSTRING_PICS' and the last double quote!

HEXSTRING_PICS outputs its string on SAVEPARAM (save parameter list in file) with a 0X prefix.

STRING_PICS Definition for ASCII String Pics/Pixit Object.

Usage:
1.) –" Prompt String"
2.) Maximal length (Maximal Size for input strings: 128 characters.)
3.) **STRING_PICS**
4.) Name of PICS/PIXIT parameter
5.) Initial String"

The string objects allow empty strings to be entered. This results in strings of zero length .

The string objects should not contain spaces (0X20), otherwise a loading of the parameter list (LOADPARAM: see Chapter 2.1) will fail.

F1_PICS Definition for enumerated Function PICS/PIXIT Object, executed on P_EXECUTE and invocation (see chapter 10.2).

Usage:
1.) Number of parameters (Functions)
2.) **F1_PICS**
3.) Name of PICS/PIXIT parameter
4.) Default Function
5.) List of Functions

F2_PICS Definition for enumerated Function PICS/PIXIT Object, executed like F1_PICS and also on P_CHANGE (see chapter 10.2).

Usage:
1.) Number of parameters (Functions)
2.) **F2_PICS**
3.) Name of PICS/PIXIT parameter
4.) Default Function
5.) List of Functions

10.2 CREATE A NEW MENU SYSTEM ENTRY

To create a new menu entry in the PARAMETER_LISTS MENU you have to write the PICS/PIXIT objects (see chapter 10.1) in a PICS–List:

PICSL: **(--)**
Starts a PICS/PIXIT–Parameter list definition.
Example: `PICSL: PICS_name`

PICSL; **(--)**
Ends a PICS/Parameter list definition

–" **(-- string address)**
Compile string into dictionary.
String definition for the objects and test cases, groups, subgroups, and suites.
Example : `–" STRING " COUNT TYPE`
The difference to the normal quote " is, that the literal buffer is not used but the string is compiled into dictionary to stay accessible.

V.C" Comment string definition for parameter lists
Example: `V.C" ( this is a string to be displayed ) " VCR`
Caution: 1. Immediately after **V.C"** a space has to be left free.
2. The string should be in brackets. This avoids compiling of the string while LOADPARAM is running. The open bracket should find a space at its left and right hand side.

Now the PICS–List to the MENU SYSTEM is to be attached:

There are 20 slots for PICS / PIXIT Parameter lists. To attach a list at position 2, type:

```
2  SET_PARAM  PICS_name
```

SET_PARAM sets the named parameter list definition into the selection menu 'PARAMETER LISTS' at the given slot. The 20 slots are numbered from 1 to 20.

SET_PARAM **(# of slot --)**
The slots are filled initially with EXIT. (1...20 SET_PARAM EXIT). The EXIT is an indication for the display not to show the line and stop.

AUTO_SET_PARAM **(--)**
Like SET_PARAM, but automatically creation of next slot number.

10.3 EXAMPLE

```
1 CONSTANT Constant_1
2 CONSTANT Constant_2


2  Constant_1  ENUM_PICS  PICS-Variable_1  Constant_1 Constant_2

-" INPUT VALUE: 0-10 " 0 10
0 DECIMAL_PICS PICS-Variable_2

-" INPUT HEX STRING. 3 OCTETS:"
3 HEXSTRING_PICS PICS-Variable_3 010203"


-" Long name" ,
PICSL: PICS_name
    V.C" ( Comment ) " VCR
    PICS-Variable_1    VCR
    V.C"              " VCR
    PICS-Variable_2    VCR
    PICS-Variable_3    VCR
PICSL;

AUTO_SET_PARAM PICS_name
```

Note: Each PICS / PIXIT or string has to be separated with VCR!
Never use two VCRs directly in sequence!
Empty lines are given with `V.C"  "  VCR.`
The long name will appear in the parameter lists selection menu.

10.4 WORDS USED BY FUNCTION: SAVEPARAM

Now follow some definitions for the SAVEPARAM and LOADPARAM functions.(See Chapter 2.1) The respective assignment symbols are used when the current contents of objects in a parameter list is written to disk or to screen. When parameter files are loaded back with LOADPARAM, the assignment symbols move the indicated contents into the objects.

:= Value assignment for longs
(ENUM_PICS, ENUM_PARAM, DECIMAL_PICS, DECIMAL_PARAM)

:$= Value assignment for strings
(STRING_PICS, HEXSTRING_PICS)

:*= Value assignment for functions
(F1_PICS, F2_PICS).

10.5 ' METHOD '

'METHOD' is a utility to change the behaviour of PICS/PIXIT parameters.

METHOD Constant. Holds the actual method for parameter objects

P_ACCESS (--)
In this case the objects behave like ordinary FORTH variables. They have an address, pointing to the data, on stack, and thus allow for reading (and writing) the values.
METHOD value = 0
Standard value for METHOD while executing test cases!!

P_SCREEN (--)
As the objects use the vectored output routines (V. routines), the output may be directed to screen, printer, RAM etc.
For disk output, first a file should be opened, then a Disk Track Buffer should be allocated and then the V.RAM directs the output to the buffer, where a VCR command may check each line if the buffer has to be written to disk.
METHOD value = 1
Example:
```
P_SCREEN
V.SCREEN
VERDICT-LOG
```
Output:
```
VERDICT-LOG := YES
```

P_CHANGE (--)
This method is usable when the PICS / PIXIT list is displayed on screen and the user wants assistance to adjust the values. When an object is called with this method, the action depends on the object class. (Used for F2_PICS)
METHOD value = 3

P_EXECUTE (--)
Set Execute Method (before using F1_PICS or F2_PICS)
METHOD value = 4

P_DEBUG (- -)

Debug output to control the syntax of a PICS/PIXIT parameter.
METHOD value = 99

Example:
```
P_DEBUG
VERDICT-LOG
```

Output:

```
CONTENTS OF VERDICT-LOG
  C94FDE 00 c9 59 4E 00 00 00 02 00 C8 8D D2 00 C8 8D C2 ..YN.............
  C94FEE 00 8A 45 4E 55 4D 5F 4D 45 4E 55 34 00 C9 4F C6 ..ENUM_MENU4 ..O .
VARIABLE= DO-VLOG* VALUE = 00000001 YES
NUMBER OF PARAMS = 2
00C88DD2 YES
00C88DC2 NO
```

11 OTHER WORDS

CASE_DISPLAY **(ON | OFF --)**
If `ON CASE_DISPLAY`, at the top right hand corner of the screen the **actual running test case** instead of the time will be shown.

BETWEEN? **(number / low / high -- flag)**
Checks if 'number' lies between (inclusive) low and high.

11.1 DEBUGGING WORDS

DEBUG Variable: Value: 0 – No debugging
Value: > 0 – The higher the value so much the more debug outputs will be given.

This words have to been called within test cases / groups ... :

T **(--)**
Trace transmit command.

T" **(--)**
Handling of command trace strings.
Example:

```
SABM T" UA OR DM [F=1] "
```

Output trace:

```
SENT : SABM , EXPECT: UA OR DM [F=1]
```

.RX **(--)**
Display last received event

.RX– **(--)**
Display last received event without VCR

STA **(--)**
Outputs current TTCN stack.

The following word is a utility for writing time–optimized receive constraints and PCO's (see chapter 9). On the other hand it gives debugging information, if a receiving condition was not met.

FALSE–> **(0 –– 0 EXIT)**
(1 ––)
Exist for Event Recognition.
Use ONLY in FORTH definitions (Constraints, ...) and NEVER in test steps and test cases. (See chapter 9)
USAGE:
```
: CONSTRAINT_name
  #GSM_SCCP #RLCS ?RX_SU
     FALSE->
;
```

F–>D **(––)**
DOER word to change the length of debugging output of FALSE–>

Example:

```
MAKE F->D DROP              ;          No debugging output of FALSE->
                                       ( Initially usage of FALSE->)
MAKE F->D DEBUGS_FALSE-> ;             Short output of FALSE->
MAKE F->D DEBUGM_FALSE-> ;             Longer output of FALSE->
```

11.1.1 ' SPY '

There is a mechanism to observe the current stack behaviour of Test steps / cases / groups, Defaults and Constraints. The contents of the stack will be displayed before and after running.

TRACE_WINDOW **(Start line / number of lines ––)**
Defines a TRACE–WIMDOW in which the SPY output will be done.

TRACE **(––)**
Opens the TRACE–window.

UNTRACE **(––)**
Closes the TRACE–window.

SPY_ON_TTCN **(––)**
Secures a TTCN definition with the 'SPY' mechanism.

SPY_OFF_TTCN **(––)**
Switches the 'SPY' mechanism off for a TTCN definition.

Example:

```
SPY_ON_TTCN testcase_name
SPY_ON_TTCN constraint_name
.
.
1 10 TRACE_WINDOW TRACE
```

11.2 VECTORED OUTPUT WORDS

These routines work similarly to the normal FORTH output routines, but the output may be directed to screen, printer etc.

V. **(number --)**
Output a number (in decimal)

V." **(--)**
Output an inline string

V.C" **(--)**
Output string in parameter list

V.ID. **(nfa --)**
Output a name of a function

VCR **(--)**
Output a carriage return (new line)

V.H **(number --)**
Output a number in Hex

V.HB **(number --)**
Output hex byte .HB

V.HH **(number --)**
Output hex nibble .HH

V.TIME **(time --)**
Output time as hh:min:ss

V.TYPE **(string pointer/count --)**
Output ascii string of length 'count'

V.TYPH **(string pointer/count --)**
Output hex string of length 'count'

V.DATE **(--)**
Output date as yy/mm/dd

V.R **(number/field length --)**
Output number in given field .R

V.SPACES **(count--)**
Output up to 77 spaces

V.DUMP **(Adr / lgth --)**
Output contents in HEX

11.2.1 SELECT THE OUTPUT CHANNEL

Following words select the output channel of the " **V.** " (vectored) words:

V.SELECTED Variable, indicates current output channel set by following words.

V.SCREEN (--)
to screen only.For debugging and hints .
V.SELECTED value = 1

V.PRINT (--)
to printer only.Caution: if used in tests in receive loops,a slow printe may cause a timeout,when a full print buffer accepts no further print commands.
V.SELECTED value = 2

V.SCREEN+PRINT
(--)
to screen and printer.
V.SELECTED value = 3

V.TRACE (--)
direct to trace: screen,capture buffer,disk.
V.SELECTED value = 4

V.TRACE+PRINT
(--)
to trace and printer .
V.SELECTED value = 6

V.CAPTURE (--)
to capture buffer only.For debugging and hints .
V.SELECTED value = 8

V.RAM (--)
direct output to RAM.
V.SELECTED value = 16

V.RAMBUF (--)
A 170 byte RAM buffer for V.RAM.

11.3 TREE

TREE is a utility to create a list of all test cases in a suite. This list shows the short and long names of test cases , subgroups and groups in a "TREE–structure".

INDENTING Variable, indicating the indentation level. Default=5

Usage:

3. Select Output Channel:
   `V.SCREEN` ,
   `V.RAM` or (For output to Disk)
   `V.PRINT`

4. Call Tree with the Structure Root Name as Parameter:
   `TREE SUITE_name`

5. If V.Ram was selected, type:
   `" filename" WTD`

   when asked to write the ASCII data to disk.

Example of output:

```
LU :  Location Update
2.1  LU/Initial Registration (LUIR)
     2.1.0  LUIR/Capability Tests (CT)
          2.1.0.1  LUIR/CT/Simple
     2.1.1  LUIR/Normal Behaviour (NB)
          2.1.1.1  LUIR/NB/Initial Message (IM)
               2.1.1.1.1  LUIR/NB/IM/DataVar-CLI3(DVCL)
                    2.1.1.1.1.1  LUIR/NB/IM/DVCL3/minLAC
                    2.1.1.1.1.2  LUIR/NB/IM/DVCL3/minLACmidCI

.
.
.
.
               2.3.2.4.4  LUPV/AB/UHLR/AbortBSS
               2.3.2.4.5  LUPV/AB/UHLR/Unexp.Data
               2.3.2.4.6  LUPV/AB/UHLR/Timeout
          2.3.2.5  LUPV/AB/Ciphering (CI)
               2.3.2.5.2  LUPV/AB/CI/AbortHLR_CiphFail
          2.3.2.6  LUPV/AB/TMSIreallocation (TMS)
               2.3.2.6.1  LUPV/AB/TMS/Timeout
               2.3.2.6.2  LUPV/AB/ClearRqst
               2.3.2.6.3  LUPV/AB/DiscInd
     2.3.3  LUPV/Complex Behaviour (CB)
          2.3.3.1  LUPV/CB/UnknSubsc.PLVR-HLR
          2.3.3.2  LUPV/CB/UnknTMSIinVLR_T3260
```

11.4 'DOER' WORDS

There are some DOER words reserved:

Note: Do NOT delete the contents of a DOER word!
Do ONLY add a function to the DOER word!

To change the contents of a DOER word:

1. Look at the old function of it:

```
DECOMP DOER_CASE1:
```

Output:

```
DOER DOER_CASE1: function_old EXIT
```

2. Define a new word with the old AND new contents in it:

```
: NEW_WORD
   function_old
   functions_new1
   functions_new2
;
```

3. Change the function of it:

```
MAKE DOER_CASE1: NEW_WORD ;
```

<DSP_VERS>	DOER word for the Software versions.*
DOER_STEP;	DOER words in STEP;
DOER_CASE1: DOER_CASE2:	DOER words in CASE:
DOER_CASE1; DOER_CASE2;	DOER words in CASE;
DOER_SUBGROUP1: DOER_SUBGROUP2:	DOER word in SUBGROUP:
DOER_SUBGROUP1; DOER_SUBGROUP2;	DOER word in SUBGROUP:
DOER_GROUP1: DOER_GROUP2:	DOER word in GROUP:
DOER_GROUP1; DOER_GROUP2;	DOER word in GROUP:
DOER_SUITE1: DOER_SUITE2:	DOER word in SUITE:
DOER_SUITE1; DOER_SUITE2;	DOER word in SUITE:
DOER_PASS	DOER word in PASS
DOER_FAIL	DOER word in FAIL

* Only applicable on CCS#7 with SSS–TE

DOER_ERRORV		DOER word in ERROR_VERDICT
DOER_INCONC		DOER word in INCONC
DOER_RUN_SEL		DOER word in RUN_SEL of the case selection menu
START_TEST_DOER	**END_TEST_DOER**	This doer words are called at the start / end of the test
START_CASE_SELECT		This doer word is called at the start of the case select menu
LEAVE_PICS_SELECT		This doer word is called when the PICS/PIXIT parameter menu is left. It is intended to use for calling the PICS/PIXIT dependent CASE SELECTION TABLE

12 SDL TESTMANAGER AND SIETEM

CONNECTION OF SIETEM TO THE CURRENT K1197 (SDL) TEST MANAGER:



Example for SIETEM called by SDL:

```
0 STATE{    OTHER_EVENT      ACTION{     TM{     }ACTION     }STATE
```

12.1 OVERVIEW



12.2 ENHANCEMENTS FOR SIETEM

There are some enhancements using the SDL test manager for SIETEM:

->TM **(No. of TM / PFA of test --)**
Starts the test step / case ....

TM= **(No. of TM --)**
Starts the following test step / case ....

TM{ **(--)**
Call the SIETEM test manager.
SYSTEM WORD!

12.3 SOURCE FILES ON BINARY DISKETTE

The following files you find as source code on you binary disk.

Usually, those files are already compiled and saved in the binary:

TMTM.B	at CCS#7 application
TMTM.B1, ... TMTM.B8	at ISDN application.

This binary will be loaded automatically by calling a test case / group / ... via menu system, or you can load it manually:

e.g.: `" TMTM.B" EXEC_TS`

If those files are **already not loaded** and there is no file TMTM.Bx you can compile and save them with:

At CCS#7 for example:
```
" M-TMTM" EXECF
" TMTM.B" SAVETS
```

FILE: M-TMTM

```
( M-TMTM                Multi-testmanager is ON          )
( TT_TMTM               Loaded by M-TMTM                 )
( S-TMTM                Multi-testmanager is OFF         )
( TMTM.B                Loaded by SIETEM                 )

#IFDEF LDTEST
    FORGET LDTEST
#ENDIF

: LDTEST
    GLOB_TCLR
    TM0 " TT_TMTM" EXECF
    TM1 " TT_TMTM" EXECF
    TM2 " TT_TMTM" EXECF
    TM3 " TT_TMTM" EXECF
    TM4 " TT_TMTM" EXECF
    TM5 " TT_TMTM" EXECF
    TM6 " TT_TMTM" EXECF
    TM7 " TT_TMTM" EXECF
    GLOB_TM_RUN
    TM0
;

#IFDEF CCS7-K1197#
  MUX_ON
#ELSE
  L3_MUX_ON
#ENDIF

LDTEST
```

FILE: TT_TMTM

```
( M-TMTM            Multi-testmanager is ON      )
( TT_TMTM           Loaded by M-TMTM             )
( S-TMTM            Multi-testmanager is OFF     )
( TMTM.B            Loaded by SIETEM             )

TCLR

#IFDEF CCS7-K1197#

0 STATE_INIT{
        1 KEY-FLAG* !           ( Receive start via FK8 )
        #UNUSED =CN_LINK        ( Connnection for link 1 to 4 )
        #UNUSED =CN_MSPC        ( Connnection for My SPC )
        #UNUSED =CN_YSPC        ( Connnection for Your SPC )
}STATE_INIT
0 STATE{
        OTHER_EVENT ACTION{
              EVENT_TYPE
               DOCASE
                   CASE #EV_FRAME
                  ORCASE #EV_LEVEL1
                  ORCASE #EV_LEVEL2
                  ORCASE #EV_TEST
                  ORCASE #EV_TM_IPC
                  ORCASE #EV_TM_TIME_OUT
                  ORCASE #EV_COMMAND
                  ORCASE #EV_EMULATION      { TM{ }
                    CASE #EV_TIME_OUT       { TIMER-NUMBER @ 51 <
                                              IF TM{ ENDIF  ( if user timer )
                                            }
                    CASE #EV_FUNCTION_KEY   { KEY-NUMBER @ UF6 =
                                              IF
                                                1 SUSPEND-FLAG !
                                              ELSE
                                                KEY-FLAG* @ IF TM{ ENDIF
                                              ENDIF
                                            }
                    CASE #EV_STRING_ENTRY   { STRING-FLAG* @ IF TM{ ENDIF
                                            }
                    CASE DUP            { }
                ENDCASE
        }ACTION
}STATE
```

```
#ELSE

0 STATE_INIT{
    0 KEY-FLAG* L!
    0 STRING-FLAG* L!
}STATE_INIT
0 STATE{
    DL-DATA#CONF ?L2_SERVICE
         ACTION{ }ACTION                          ( ignore acknowledging RRs )

    UF6 ?KEY
    ACTION{
             1 SUSPEND-FLAG L!
    }ACTION
    OTHER_EVENT
    ACTION{
        EVENT-TYPE @
        DOCASE
            CASE STRING-ENTRY# {    STRING-FLAG* @ IF TM{ ENDIF    }
            CASE FUNCTION-KEY# {    KEY-FLAG* @    IF TM{ ENDIF    }
            CASE DUP           {    TM{                            }
        ENDCASE
    }ACTION
}STATE

#ENDIF
```

12.4 EXAMPLE

This example makes use of the SIETEM enhancements:

Four SDL–Test Managers are used to call parallel SIETEM test cases.

Testmanager: TM0	Testmanager: TM1	Testmanager: TM2	Testmanager: TM3
SDL: TT_TMTM	SDL: TT_TMTM	SDL: TT_TMTM	SDL: TT_TMTM

0 STATE{
TM{
}STATE
	0 STATE{
	TM{
	}STATE
		0 STATE{
		TM{
		}STATE
			0 STATE{
			TM{
			}STATE

TTCN: T0	TTCN: T1	TTCN: T2	
CASE: T0	STEP: +PRE1	CASE: T2 ? #GISUP	
? UF1 ?KEY 2 1 TM_IPC_SEND	STEP;	? 1 ANY#TM	
? 1 1 ?TM_IPC	CASE: T1 +PRE1 ? 2 0 ?TM_IPC	CASE;	
? 1 2 ?TM_IPC	? #GISUP		
? UF2 ?KEY 1 1 TM_IPC_SEND 1 2 TM_IPC_SEND	? 1 ANY#TM		
CASE;	CASE;		

Compile this testscenario with:

```
" TTL.F" EXEC
```

Start this testscenario manually with:

```
" M-TMTM" EXECF
0 TM= TEST1
```

Start this testscenario by SIETEM menu system:

select TEST1
f8 RUN_SEL

Source code of those files:

FILE: TTL.F

```
MAKE FILES
    0
    " TTG.F"
    " TT0.F"
    " TT1.F"
    " TT2.F"
;

FILES LOAD_FILES
```

FILE: TT0.F

```
0 VARIABLE tn-run


ON ATCM

STEP: T0
    ? UF1 ?KEY
        V." T0: Mail to TM1" VCR
        2 1 TM_IPC_SEND
        REMAIN

    ? 1 1 ?TM_IPC
        V." TM1 finished" VCR
        -1 tn-run +!
        tn-run @ IF REMAIN ENDIF

    ? 1 2 ?TM_IPC
        V." TM2 finished" VCR
        -1 tn-run +!
        tn-run @ IF REMAIN ENDIF

    ? UF2 ?KEY
        V." T0: Shut down all TMs" VCR
        1 1 TM_IPC_SEND
        1 2 TM_IPC_SEND
STEP;

OFF ATCM
```

FILE: TT1.F

```
ON ATCM

STEP: +PRE1
    #SPAL3 DUP SD ML START_LINK                ( Start CCS#7 layer 2
                                                emulation on port 1 )
    #SPBL3 DUP SD ML SET_EMERGENCY START_LINK  ( Start it on port 2 )
    " TEST.P" LOAD_POOL                       ( All messages to be sent must
                                                be included in 'TEST.P' )
    1 KEY-FLAG* L!                            ( inform TMTM to allow
                                                keyboard input to the test
                                                cases )

STEP;

OFF ATCM

ON ATCM

STEP: T1
    +PRE1
    ? 2 0 ?TM_IPC
        V." T1: ISUP-Call" VCR
        " IAM" SEND_MSG

        ? #GISUP #DI_ACM ?RX_SU
            V." T1: Adress complete" VCR

          ? #GISUP #DI_ANS ?RX_SU
            V." T1: Connection" VCR

            ? 2 0 ?TM_IPC
                V." T1: Release" VCR
                " REL" SEND_MSG
                " RLSD" SEND_MSG

                ? #GISUP #DI_RLC ?RX_SU
                  V." T1: Release complete" VCR
                  1 0 TM_IPC_SEND

                ? 1 ANY#TM ?TM_IPC
                    V." T1: Mail received. Shutdown T1" VCR

            ? 1 ANY#TM ?TM_IPC
                V." T1: Mail received. Shutdown T1" VCR

        ? #GISUP #DI_UBM ?RX_SU
            V." T1: No connection possible" VCR

        ? 1 ANY#TM ?TM_IPC
            V." T1: Mail received. Shutdown T1" VCR

    ? 1 ANY#TM ?TM_IPC
        V." T1: Mail received. Shutdown T1" VCR
STEP;

OFF ATCM
```

FILE: TT2.F

```
ON ATCM

STEP: T2
    ? #GISUP #DI_IAM ?RX_SU
        " ACM" SEND_MSG
        " ANS" SEND_MSG

        ? #GISUP #DI_REL ?RX_SU

            ? #GISUP #DI_RLSD ?RX_SU
                " RLC" SEND_MSG
                  1 0 TM_IPC_SEND

            ? 1 ANY#TM ?TM_IPC
                V." T2: Mail received. Shutdown T2" VCR

        ? 1 ANY#TM ?TM_IPC
            V." T2: Mail received. Shutdown T2" VCR

    ? 1 ANY#TM ?TM_IPC
        V." T2: Mail received. Shutdown T2" VCR
STEP;

OFF ATCM
```

FILE: TTG.F

```
ON ATCM

-" ISUP-CALL" ,
CASE: TEST1
    2 tn-run L!
    1 ' T1 ->TM              ( Start case T1 on TM1 )
    2 ' T2 ->TM              ( Start case T2 on TM2 )
    T0

CASE;

-" LOADER" ,
GROUP: GROUP-1
    TEST1
GROUP;

-" SUITY" ,
SUITE: ALL
    GROUP-1
SUITE;

AUTO_SET_SUITE ALL

OFF ATCM
```

INDEX

Symbols

.RX, 11–1
.RX–, 11–1
!, 5–1
!SHUTDOWN, 5–6
?, 5–1
?PASS, 8–1
?SHUTDOWN, 5–6
:$=, 10–5
:*=, 10–5
:=, 10–5
(F), 8–1
(FAIL), 8–1
(I), 8–1
(INCONC), 8–1
(P), 8–1
(PASS), 8–1
#DR0, 3–4
#DR1, 3–4
#WD0, 3–4
#WD1, 3–4
#WD2, 3–4
#WD3, 3–4
#WD4, 3–4
#WD5, 3–4
#WD6, 3–4
#WD7, 3–4
–", 6–2, 10–4
–>TM, 12–2

A

ALL_LINES, 2–6
ATCM, 5–1
AUTO_SET_PARAM, 10–4
AUTO_SET_SUITE, 6–4

B

BETWEEN?, 11–1

C

CASE;, 6–2
CASE:, 6–2
CASE_DISPLAY, 11–1
CASE_SEPARATOR, 3–10
CGS, 7–1
CGS_HEADER_DATE, 3–10
CHAR#REPORT, 3–5
CLIENT–STRING, 3–3
COMMAND, 2–1
COMPLETE#REPORT, 3–5
CONF_TEST, 4–1
CURR_CGS_SEL?, 7–3
CURRENT–CGS–PFA, 7–3

D

DEBUG, 11–1
DEBUGM_FALSE–>, 11–2
DEBUGS_FALSE–>, 11–2
DECIMAL_PARAM, 10–2
DECIMAL_PICS, 10–2
DEFAULT;, 5–5
DEFAULT:, 5–5
DEFAULT=, 5–5
DESELECT_CGS, 7–2
DESELECT_CGSP, 7–2
DISKLOG_FAIL, 3–4
DISKLOG_INCONC, 3–4
DISKLOG_PASS, 3–4
DOER_CASE1;, 11–6
DOER_CASE1:, 11–6
DOER_CASE2;, 11–6
DOER_CASE2:, 11–6
DOER_ERRORV, 11–7
DOER_FAIL, 11–6
DOER_GROUP1;, 11–6
DOER_GROUP1:, 11–6
DOER_GROUP2;, 11–6
DOER_GROUP2:, 11–6
DOER_INCONC, 11–7
DOER_PASS, 11–6

DOER_RUN_SEL, 11–7
DOER_STEP1;, 11–6
DOER_SUBGROUP1;, 11–6
DOER_SUBGROUP1:, 11–6
DOER_SUBGROUP2;, 11–6
DOER_SUBGROUP2:, 11–6
DOER_SUITE1;, 11–6
DOER_SUITE1:, 11–6
DOER_SUITE2;, 11–6
DOER_SUITE2:, 11–6
DSP_VERS, 11–6

E

END_LINE, 2–6
END_TEST_DOER, 11–7
ENUM_PARAM, 10–2
ENUM_PICS, 10–2
ERROR_VERDICT, 8–1
EXEC_TS, 12–3
EXIT–>, 5–6

F

F, 8–1
F–>D, 11–2
F1_PICS, 10–3
F2_PICS, 10–3
FAIL, 8–1
FAIL–IMMED–DISPLAY, 3–12
FALSE–>, 11–2
FORM#FEED, 3–10

G

GROUP;, 6–3
GROUP:, 6–3
GROUP_SEPARATOR, 3–10

H

HEADER–STRINGS, 3–3
HELP, 2–1
HEX#REPORT, 3–5
HEXSTRING_PICS, 10–3
HORIZONTAL–BAR, 3–10
HORIZONTAL=BAR, 3–10

I

IF?, 5–2
INC, 8–1
INCONC, 8–1
INCONC–IMMED–DISPLAY, 3–12
INDENTING, 11–5

L

L!, 5–1
L1_COMPLETE#REPORT, 3–6
L1_NONE#REPORT, 3–6
L1_SHORT#REPORT, 3–6
L2_CHAR#REPORT, 3–6
L2_COMPLETE#REPORT, 3–6
L2_HEX#REPORT, 3–6
L2_NONE#REPORT, 3–6
L2_SHORT#REPORT, 3–6
L3_CHAR#REPORT, 3–6
L3_HEX#REPORT, 3–6
L3_MNEMONIC#REPORT, 3–6
L3_NONE#REPORT, 3–6
L3COMPLETE#MODE, 3–6
L3MEDIUM1#MODE, 3–6
L3MEDIUM2#MODE, 3–6
L3SHORT#MODE, 3–6
LEAVE_PICS_SELECT, 11–7
LINE_AFTER_VERDICT, 3–10
LOAD, 2–1
LOAD_PARAM, 2–4
LOCK_SELECT, 7–2
LOCK_SELECTP, 7–2
LOCKED?, 7–3
LOG, 3–3
LOG#CASE, 3–3
LOG#LONG, 3–4, 3–5
LOG#OFF, 3–3
LOG#SHORT, 3–4, 3–5
LOG–DRIVE, 3–4

LOG_SELECT, 3–3
LOGHEAD–PARAMLIST–OUTPUT, 3–3

M

M–TMTM, 12–3
METHOD, 10–6

N

NO_LOOP!, 5–6

O

ONE_FILE_PER_CASE/GROUP, 3–4
ONLY–CASES–WITH–VERDICTPASS, 3–9

P

P, 8–1
P_ACCESS, 10–6
P_CHANGE, 10–6
P_DEBUG, 10–7
P_EXECUTE, 10–6
P_SCREEN, 10–6
PASS, 8–1
PASS–IMMED–DISPLAY, 3–12
PD, 8–1
PICSL;, 10–4
PICSL:, 10–4
PRINT, 2–6
PRINT#CHAR, 3–7
PRINT#COMP, 3–7
PRINT#HEX, 3–7
PRINT#MED, 3–7
PRINT#MED2, 3–7
PRINT#MED3, 3–7
PRINT#MED4, 3–7
PRINT#MED5, 3–7
PRINT#OFF, 3–7
PRINT#SHRT, 3–7
PRINT–L1–REPORT–TYPE, 3–6
PRINT–L1REPORT–TYPE, 3–8
PRINT–L2–REPORT–TYPE, 3–6
PRINT–L2REPORT–TYPE, 3–8
PRINT–L3–REPORT–MODE, 3–6
PRINT–L3–REPORT–TYPE, 3–6
PRINT–L3REPORT–TYPE, 3–7
PRINT–L4REPORT–TYPE, 3–7
PRINT–REPORT–TYPE, 3–5
PRINT–SCCPREP–TYPE, 3–7
PRINT–TCAPREP–TYPE, 3–7
PRINTLOG_FAIL, 3–5
PRINTLOG_INCONC, 3–5
PRINTLOG_PASS, 3–5

Q

QUIT_MENU, 2–1
QUIT_STAT, 2–7
QUIT_VLOG, 2–6

R

REGUILATORY_CAMPAIGN, 7–2
REGULATORY_CAMPAIGN, 3–9
REMAIN, 5–7
REMAIN_DEFAULT, 5–7
RESCAN, 5–6
RESTRICTED_CASES/GROUPS/SUITES, 3–9, 7–2
RETURN, 5–7
RUN–SELECTION–MODE, 3–9
RUN_SEL, 2–5, 8–2

S

SAVE, 2–1
SAVEPARAM, 2–4
SEL?, 7–3
SEL–BIT–TABLE, 7–2
SEL_ALL, 2–5
SEL_NONE, 2–5
SELECT+–, 2–5
SELECT_CGS, 7–2
SELECT_CGSP, 7–2
SELECTED?, 7–1

SET_PARAM, 10–4
SET_SUITE, 6–4
SHORT#REPORT, 3–5
SPY_OFF_TTCN, 11–2
SPY_ON_TTCN, 11–2
STA, 11–1
START_CASE_SELECT, 11–7
START_TEST_DOER, 11–7
STARTLINE, 2–6
STATIS, 2–5
STEP;, 6–2
STEP:, 6–2
STRING_PICS, 10–3
SUBGROUP;, 6–3
SUBGROUP:, 6–3
SUITE;, 6–3
SUITE:, 6–3
SUT–STRING, 3–3

T

T, 11–1
T", 11–1
TEST–LAB–STRING, 3–3
TM{, 12–2
TM=, 12–2
TMTM.B, 12–3
TMTM.B1, 12–3
TMTM.B2, 12–3
TMTM.B3, 12–3
TMTM.B4, 12–3
TMTM.B7, 12–3
TMTM.B8, 12–3
TRACE, 11–2
TRACE_WINDOW, 11–2
TREE, 11–5
TT_TMTM, 12–4
TTCN, 1–1

U

ULTIMATE_FAIL, 5–6
UNLOCK_SELECT, 7–2
UNLOCK_SELECTP, 7–2
UNTRACE, 11–2

V

V., 11–3
V.", 11–3
V.C", 10–4, 11–3
V.CAPTURE, 11–4
V.DATE, 11–3
V.DUMP, 11–3
V.H, 11–3
V.HB, 11–3
V.HH, 11–3
V.ID., 11–3
V.PRINT, 11–4
V.R, 11–3
V.RAM, 11–4
V.RAMBUF, 11–4
V.SCREEN, 11–4
V.SCREEN+PRINT, 11–4
V.SELECTED, 11–4
V.SPACES, 11–3
V.TIME, 11–3
V.TRACE, 11–4
V.TRACE+PRINT, 11–4
V.TYPE, 11–3
V.TYPH, 11–3
VCR, 11–3
VERDICT?, 8–2
VERDICT–LOG, 3–11
VERDICT–LOG–FAIL–IMMED, 3–11
VERDICT–LOG–INCONC–IMMED, 3–11
VERDICT–LOG–PASS–IMMED, 3–11
VERDICT–STATISTICS–GROUP, 3–11
VERDICT–STATISTICS–SUBGROUP, 3–11
VERDICT–STATISTICS–SUITE, 3–11
VERSION, 2–1

VLOG, 2–1, 2–6

WTD, 11–5

W

WAIT_TIME_AFTER_CASE, 3–9

Y

YES_LOOP!, 5–6

Bestell-Nr. für Registersatz 6ZB5900-0AL00-8AA1
919112 06935

Bestell-Nr. für Registersatz 6ZB5900-0AL00-8AA1
919112 06935.

Bestell-Nr. für Registersatz 6ZB5900-0AL00-8AA1
919112 06935.

Bestell-Nr. fur Registersatz 6ZB5900-0AL00-8AA1
919112 06935

Bestell-Nr. für Registersatz 6ZB5900-0AL00-8AA1
919112 06935

Bestell-Nr. für Registersatz 6ZB5900-0AL00-8AA1
919112 06935.

Bestell-Nr. für Registersatz 6ZB5900-0AL00-8AA1
919112 06935

Bestell-Nr. für Registersatz 6ZB5900-0AL00-8AA1
919112 06935.

Bestell-Nr. für Registersatz 6ZB5900-0AL00-8AA1
919112 06935.